

NOTES:


1. HOLD ROUGH-IN DIMENSIONS $\pm 1/4"$ (6.4mm).
2. WHEN INSTALLING THIS UNIT, LOCAL, STATE, OR FEDERAL CODES SHOULD BE ADHERED TO. INSTALL A SCREWDRIVER STOP IN THE SUPPLY LINE IF REQUIRED (SEE PAGE 9 FOR SUGGESTED WATER STOP LOCATION)
3. INSTALLATION LOCATION/HEIGHT MUST BE COMPLIANT WITH ADA REGULATIONS.

- CONTINUED ON SHEET 2 -

INSTALLATION STEPS:

1. IDENTIFY A SUITABLE LOCATION TO MOUNT THE FILTER CABINET NEAR YOUR WATER DISPENSER. THE FILTER CABINET SHOULD BE MOUNTED HORIZONTALLY LEVEL, AS SHOWN, PREFERABLY CENTERED ON TWO WALL STUDS.
 2. SHUT OFF WATER AND POWER TO THE WATER DISPENSER.
 3. REMOVE COVER PANEL BY REMOVING (2) #8-32 COVER SCREWS (T20 TORX) AND SET ASIDE ALL LOOSE ITEMS.
 4. PLACE FILTER CABINET ON THE WALL IN DESIRED LOCATION USING A BUBBLE LEVEL TO ENSURE ACCURACY.
 5. MARK THE MOUNTING HOLES AND REAR ACCESS AREA WITH A PENCIL FOR THROUGH WALL PLUMBING.
- IF WATER LINES WILL NOT BE PLUMBED THROUGH WALL, USE KNOCK-OUTS TO ALLOW PLUMBING ACCESS THROUGH THE SIDES OR BOTTOM OF THE CABINET.
- NOTE:** USE INCLUDED KNOCK-OUT HOLE GROMMETS TO PROTECT WATER LINES FROM SHARP EDGES.
6. CUT A HOLE IN THE WALL WITHIN THE MARKED AREA TO ALLOW ACCESS FOR THROUGH WALL PLUMBING.
 7. REMOVE PROTECTIVE FILM FROM THE OUTSIDE OF THE FILTER CABINET AND COVER PANEL.
 8. MOUNT CABINET TO WALL USING (4) #10 STRUCTURAL SCREWS (NOT SUPPLIED).
 9. PLUMB WATER SUPPLY TO THE FILTER CABINET INLET, 3/8" PUSH-TO-CONNECT 1/4 TURN VALVE (SEE PAGE 9).
 10. CONNECT SUPPLY TUBING FROM OUTLET FITTING ON THE FILTER MONITOR TO THE INLET OF THE WATER DISPENSER.
 11. INSTALL WATER FILTER BY KEYING THE ALIGNMENT TABS, PUSHING INWARDS AND TURNING CLOCKWISE.
 12. REFER TO START-UP INSTRUCTIONS (PAGE 3) TO COMPLETE INSTALL.


		1455 KLEPPE LANE SPARKS, NEVADA 89431 (775) 359-4712 FAX (775) 359-7424 E-MAIL: HAWS@HAWSCO.COM WEBSITE: WWW.HAWSCO.COM	
		ECN: 6320 DRAWN: DN APPROVED: DN	REV. ECN: 6320 DATE: 12/04/25 DATE: 01/07/26
PART NUMBER 0510002336.D			REVISION 1
SCALE: 1:10 DRAWING TYPE: INSTALLATION		SIZE: A SHEET 1 OF 2	



NOTES:

4. NOTE DIRECTION OF FLOW ARROWS ON FILTER HEAD AND FILTER MONITOR SENSOR.
5. CUT ALL TUBING SQUARE AND CLEAN AS REQUIRED. ENSURE TUBING IS FULLY INSERTED INTO ALL PUSH-TO-CONNECT FITTINGS.
6. IF USING A COMPRESSION WATER SUPPLY STOP, CONNECT THE WATER SUPPLY LINE TO THE SUPPLY STOP USING COMPRESSION NUT (INCLUDED WITH YOUR SUPPLY STOP), FOLLOWED BY THE PLASTIC FERRULE (SUPPLIED), AND THE BRASS TUBE SUPPORT (SUPPLIED). INSERT SUPPLY LINE INTO THE SUPPLY STOP UNTIL IT BOTTOMS OUT. THREAD THE NUT ONTO THE SUPPLY STOP UNTIL FINGER TIGHT. PUT A LINE ON THE NUT USING A MARKER. TIGHTEN EXACTLY ONE ADDITIONAL FULL TURN (360 DEG) WITH A WRENCH, USING THE LINE TO COUNT TURNS.

*NOTE THE CORRECT ORIENTATION OF THE PLASTIC FERRULE.
 *DO NOT USE THE BRASS FERRULE INCLUDED WITH YOUR SUPPLY VALVE ON POLY TUBING.



1455 KLEPPE LANE
 SPARKS, NEVADA 89431
 (775) 359-4712 FAX (775) 359-7424
 E-MAIL: HAWS@HAWS.CO.COM
 WEBSITE: WWW.HAWS.CO.COM

ECN: 6320	REV. ECN: 6320	BY: DN	MODEL(S)	PART NUMBER
DRAWN: DN	DATE: 12/04/25	CHKD: JU	6478, FILTER CABINET WITH MONITOR	0510002336.D
APPROVED: DN	DATE: 01/07/26	SCALE: 1:3	DRAWING TYPE: INSTALLATION	REVISION 1
SHEET 2 OF 2				